

## Index

- Bearing outer race**
  - removing/installing 34.19
- Breather sleeve**
  - installing 34.17
- Differential lock control unit**
  - removing/installing 34.11
- Drive flange**
  - circlip 34.18
  - removing 34.17
- Fifth/reverse gear lock**
  - assembling 34.19
  - installation position 34.19
- Final drive housing**
  - assembly 34.15
  - bearings 34.16
  - modification (for 20V engine) 34.9
- Inner shift rod**
  - and relay shaft, installing 34.22
  - oil seal, replacing 34.22
- Main shaft**
  - assembly 34.20
- Multi-function sender**
  - installing 34.17
- Oil collector**
  - removing/installing 34.22
- Relay shaft bolts**
  - removing 34.21
- Selector shaft bushing**
  - removing 34.21
- Shift fork bearing**
  - removing/installing 34.22
- Shift mechanism**
  - installation position 34.21
- Shift rod bushing**
  - removing 34.17
- Technical data**
  - ★ ■ chart 34.3
- Transmission**
  - assembling/disassembling 34.13
  - removing/installing 34.7
- Vacuum operations for differential lock**
  - assembly 34.10
  - hose layout 34.12
- Cap**
  - removing 34.25
- Center differential/final drive**
  - assembly 34.23
  - bearings 34.24
  - installing 34.26
- Drive flange**
  - removing 34.25
- Main shaft ball bearing**
  - installing 34.27
- Needle bearing**
  - removing/installing 34.25
- \*Oil drilling in main shaft**
  - deleted 34.27

★ **NEW INFORMATION** since last filming

**This page  
intentionally  
left blank**

## Technical data, 5-speed transmission 01A

### Note

For location of transmission codes, see Group 00.

| Code                              |              | AKT  | AKU                             | AXL   |
|-----------------------------------|--------------|--|---------------------------------|-------|
| Production                        | from         | 06/87  | 06/87                           | 09/90 |
|                                   | to           |  | 09/90                           |       |
| Application                       | type         | Audi 80 Quattro                                      | Audi 80 Quattro/Audi 90 Quattro |       |
|                                   | engine       | 2.0 liter - 83 kW                                    | 2.3 liter - 101 kW              |       |
| Rear final drive                  |              | AEX  | AEC/ARS                         |       |
| Ratio                             | final drive  | 41:09 = 4.556  | 37:09 = 4.111                   |       |
|                                   | 1st gear     | 39:11 = 3.545  | 39:11 = 3.545                   |       |
|                                   | 2nd gear     | 40:19 = 2.105  | 40:19 = 2.105                   |       |
|                                   | 3rd gear     | 39:30 = 1.300  | 39:30 = 1.300                   |       |
|                                   | 4th gear     | 32:36 = 0.889  | 33:35 = 0.943                   |       |
|                                   | 5th gear     | 29:40 = 0.725  | 30:39 = 0.769                   |       |
|                                   | reverse gear | 35:10 = 3.500  | 35:10 = 3.500                   |       |
| Speedometer                       |              | electric   |                                 |       |
| Lubricant capacity                |              | 2.85 liters (3.0 US qt)                              |                                 |       |
| Lubricant type                    |              | Transmission oil G 50 (synthetic oil)<br>SAE 75 W 90 |                                 |       |
| Clutch actuation                  |              | hydraulic  |                                 |       |
| Clutch disc diameter              |              | 228 mm   | 228 mm                          |       |
| Drive flange diameter             |              | 100 mm   | 100 mm                          |       |
| Speed in highest gear at 1000 RPM |              | 33.63 km/h<br>(20.9 mph)                             | 34.17 km/h<br>(21.2 mph)        |       |

## Technical data, 5-speed transmission 01A

### Note

For location of transmission codes, see Group 00.

| Code                                     |              | ASZ  | AXM   | AKU                         | AXL   |
|--|--------------|--|-------|-----------------------------|-------|
| <b>Production</b>                        | from         | 11/88  | 10/90 | 07/86                       | 10/90 |
|  | to           | 10/90  |       | 10/90                       |       |
| <b>Application</b>                       | type         | Coupe Quattro  |       | Audi 90 Quattro 20V         |       |
|  | engine       | 20 valve 2.3 liter - 125 kW                          |       | 20 valve 2.3 liter - 125 kW |       |
| <b>Rear final drive</b>                  |              | AEC, ARS   |       | AEC, ARS                    |       |
| <b>Ratio</b>                             | final drive  | 37:09 = 4.111  |       | 37:09 = 4.111               |       |
|  | 1st gear     | 39:11 = 3.545  |       | 39:11 = 3.545               |       |
|  | 2nd gear     | 40:19 = 2.105  |       | 40:19 = 2.105               |       |
|  | 3rd gear     | 40:28 = 1.429  |       | 39:30 = 1.300               |       |
|  | 4th gear     | 35:34 = 1.029  |       | 33:35 = 0.943               |       |
|  | 5th gear     | 31:37 = 0.838  |       | 30:39 = 0.769               |       |
|  | reverse gear | 35:10 = 3.500  |       | 35:10 = 3.500               |       |
| <b>Speedometer</b>                       |              | electric   |       |                             |       |
| <b>Lubricant capacity</b>                |              | 2.85 liters (3.0 US qt)                              |       |                             |       |
| <b>Lubricant type</b>                    |              | Transmission oil G 50 (synthetic oil)<br>SAE 75 W 90 |       |                             |       |
| <b>Clutch actuation</b>                  |              | hydraulic  |       |                             |       |
| <b>Clutch disc diameter</b>              |              | 240 mm   |       | 228 mm                      |       |
| <b>Drive flange diameter</b>             |              | 100 mm   |       | 100 mm                      |       |
| <b>Speed in highest gear at 1000 RPM</b> |              | 33 km/h<br>(20.5 mph)                                |       | 35 km/h<br>(21.7 mph)       |       |


**This page  
intentionally  
left blank**

**This page  
intentionally  
left blank**

## Transmission, removing/installing

### Removing

- disconnect battery ground strap
- remove 3 upper engine/transmission bolts
- disconnect ground strap from transmission
- remove wiring connectors for speedometer sender and multi-function sender
- disconnect wiring for oxygen sensor and oxygen sensor heating element
- remove engine protection plate
- disconnect exhaust pipe from manifold
- separate exhaust pipe behind catalyst and remove pipe and catalyst
- remove drive shaft
- remove rear cross member
- remove shift rod securing bolt at transmission and let shift rod hang
- remove transmission cover plate
- remove right axle shaft shield
- disconnect left and right axle shafts, turn steering to right lock and tie both drive shafts up
- remove clutch slave cylinder
- remove tie rod coupling from steering rack and turn wheels to the left
- support engine with **10-222A**
- support transmission with **VW 1383**
- remove transmission strut at left rear and front engine mount
- remove heat shield from bonded rubber bushing
- remove bonded rubber bushing support bracket from transmission
- remove bonded rubber bushing
- remove bolt for seat belt tensioning cable guide at left rear of transmission. Position cables and guide out of way
- lower right rear subframe by loosening mounting bolts (**arrow**)
- remove remaining engine/transmission bolts
- remove transmission



## Installing

Proceed in reverse order of removal and note the following:

- press clutch master cylinder in with a lever until retaining bolt can be installed

## Note

Be sure that centering (dowel) sleeves are in cylinder block before reassembly.

## Tightening torques

### Transmission to engine

|            |                  |
|------------|------------------|
| M 8 bolts  | 25 Nm (18 ft lb) |
| M 10 bolts | 45 Nm (33 ft lb) |
| M 12 bolts | 65 Nm (48 ft lb) |

### Drive shaft to flange

|           |                  |
|-----------|------------------|
| M 8 bolts | 45 Nm (33 ft lb) |
|-----------|------------------|

### Subframe mounting bolts


|  |                  |
|--|------------------|
| M 10 bolts                                 | 35 Nm (25 ft lb) |
| after tightening, turn 90° (1/4 turn) more |                  |

### Drive shaft to transmission and final drive

|           |                  |
|-----------|------------------|
| M 8 bolts | 55 Nm (40 ft lb) |
|-----------|------------------|

### Tie rod coupling bolts to steering rack

|                  |
|------------------|
| 45 Nm (33 ft lb) |
|------------------|




## Mounting transmission to engine

- 1— Bolt M 12 x 70
- 2— Bolt M 12 x 70
- 3— Bolt M 12 x 90
- 4— Bolt M 12 x 80
- 5— Bolt M 8 x 40
- 6— Bolt M 10 x 50
- 7— Bolt M 10 x 40
- 8— Bolt M 8 x 40
- 9— Bolt M 10 x 120
- 10— Bolt M 12 x 100
- 11— Bolt M 12 x 70

Centering (dowel) sleeves:  
positions 3 and 11



## Final drive housing, modification (vehicles with 20 valve engine)




If during repairs the final drive housing is replaced, the right side mounting eye must be removed.

- saw off eye (**arrow**) as indicated by dotted line in illustration

### CAUTION

Mounting eye will contact exhaust system unless removed before installing transmission.

# Manual Transmission – Controls, Assembly



34-1902

## Differential lock control unit, removing/installing

### Removing


#### Note

For repair of system electrical components, refer to wiring diagrams and troubleshooting information in Repair Group 97.


- remove vacuum hoses
  - **A** blue = to lock servo
  - **B** yellow = to lock servo vacuum element
  - **C** violet = from intake manifold
- remove wiring connector from control unit (**arrow**)
- remove control unit mounting screws

### Installing

- to install the control unit, proceed in reverse order of removal




## Hose layout for differential lock



34-1904

|    | Length (mm) | Color  |                      |
|----|-------------|--------|----------------------|
| 8  | 1020        | white  | tubes                |
| 9  | 815         | violet | 4 x 1                |
| 10 | 2970        | violet | (to intake manifold) |
| 11 | 45          | black  | hoses                |
| 12 | 100         | black  | 3.5 x 2              |
| 13 | 390         | black  |                      |
| 14 | 900         | blue   | hoses                |
| 15 | 900         | yellow | 3.5 x 2.25           |

# Manual Transmission – Controls, Assembly



## Transmission, disassembling/ assembling

### Disassembling

- clamp transmission in assembly stand, page 34.16
- drain transmission oil
- remove clutch return lever and clutch release bearing
- remove guide sleeve
- remove and measure thickness of circlip in front of ball bearing
- pull ball bearing out of transmission housing using puller, page 34.16
  
- remove and measure thickness of circlip behind ball bearing
- remove bolts between gear carrier housing/cover (for Torsen differential) and remove cover with Torsen differential
- remove bolts between transmission housing/gear carrier housing and take off gear carrier housing
- remove multi-function sender
- remove relay shaft bolts, page 34.21
- remove locking segment bolt and take locking segment out
- remove main shaft, pinion, relay shaft, selector rods and shift forks together

### Assembling

Assemble in reverse order of procedure shown above and note the following:

- main shaft, pinion with hollow shaft, relay shaft, selector rods and shift forks must be installed together, page 34.21
- circlips for main shaft at ball bearing must be replaced in the same position and be of the same thickness


## Note

Before installing gear carrier housing, make sure that the centering sleeves are mounted in transmission housing.

## Note

Handle speedometer sender carefully. Do not let it fall, otherwise speedometer data may not be exact.


**Transmission-housing**  
 clamp transmission in assembly stand Fig. 1  
 remove sealing ring for drive flange with **VW 681**, drive in 5 mm under transmission housing surface with **VW 195**  
 note breather insertion depth Fig. 5  
 tapered roller bearing outer race, removing Fig. 12  
 drive in with **30-205** selector rod bushing, removing Fig. 6 seal with **AMV 188 200 03**



## CAUTION

If transmission housing or tapered roller bearing for pinion or hollow shaft is to be replaced and the deviation  $r$  is not specified on the bevel gear, the position of the pinion must be determined before removal of the gear carrier housing (actual measurement), see Repair Group 39.


34-1818



► Fig. 1 Transmission, mounting in assembly stand

**Note**

Mount transmission so that top of transmission faces VW 309. If holes do not align modify VW 353. This method of mounting makes measuring for S1 and S2 possible.




► Fig. 2 Ball bearing, removing from housing

- A — puller VW 1528 and gripper VW 1582/2

**Note**

When installing puller do not damage the ball bearing cage.



► Fig. 3 Ball bearing, installing in housing

- install circlip on main shaft
- pull main shaft into transmission housing and ball bearing with bolt
  - installation position: open side of plastic cage points towards guide sleeve


Beginning with transmission 21 07 9, the threaded hole in the main shaft, which is used for installing the ball bearing, is discontinued.

When installing the bearing in transmissions without the threaded hole, use tool 3235. The procedure for removing the bearing is unchanged.

- install thrust pad A (part of tool 3235) on bearing
- press bearing in by turning two bolts B alternately in stages

**Note**


The ends of bolts B must align with the two depressions in the thrust pad when pressing.




**CAUTION**

Turn each bolt ONLY a half turn at a time to prevent damage to the bearing.







- **Fig. 4 Multi-function sender, installing**
- install lock ring to seal multi-function sender




- **Fig. 5 Transmission breather sleeve, installing**



- **Fig. 6 Shift rod bushing, removing**
- with puller A, i.e. Kukko 21/3 18.5 mm - 23.5 mm




- **Fig. 7 Drive flange, removing**
- put chisel or spacer A under drive flange and pull drive flange out of differential gear by turning bolt B




► Fig. 8 Drive flange circlip, removing/installing

- clamp drive flange in vise with protective jaw covers. Press circlip out of drive flange groove with new circlip A




► Fig. 9 Tapered roller bearing outer race in final drive cover, removing

- with puller and holder A, i.e. Kukko 21/7 = 46 mm - 56 mm and Kukko 22/2
- outer race can also be removed with 3138




► Fig. 10 Tapered roller bearing outer race for final drive cover, installing



► Fig. 11 Drive flange sealing ring, installing

- drive sealing ring in 5 mm under cover upper edge




► **Fig. 12 Tapered roller bearing outer race in transmission housing, removing/installing**

- remove with puller and holder **A**, i.e.
  - Kukko 21/7 = 46 mm - 56 mm and
  - Kukko 22/2

**Note**

Install, using 30-205




► **Fig. 13 5th and reverse gear lock, assembling**

- 1 - plastic bushing
- 2 - lock ring
- 3 - bushing with lock for 5th and R gear
- 4 - spring

**Assembly Instructions**

- place spring 4 in plastic bushing 1
- turn spring counterclockwise under light pressure until spring snaps in place in base of plastic part
- place bushing 3 on spring so that bent end of spring lies in groove
- press spring together using bushing 3
  - approximately one turn counterclockwise (turn to left), until bushing tab 3 lies over the groove in plastic bushing
- press bushing tab 3 into groove in plastic bushing 1 to stop surface
- turn bushing 3 in clockwise direction (to the right) and release
  - bushing 3 springs into assembly end position




► **Fig. 14 5th/reverse gear lock, installation position**

- 5th/reverse gear bushing tab (arrow **A**) must always come to stop opposite groove (arrow **B**) on plastic bushing

**Note**


If there is any catching or hanging up in 5th or reverse gear after adjusting the shifting control, the 5th and reverse gear lock must first be removed, checked, and if necessary replaced, before removal and disassembly of the transmission.




### CAUTION

If transmission housing or tapered roller bearing for pinion or hollow shaft is to be replaced and the deviation  $r$  is not specified on the bevel gear, the position of the pinion must be determined before removal of the gear carrier housing (actual measurement), see Repair Group 39.

34-1928




► Fig. 1 Relay shaft bolts (arrows), removing




► Fig. 2 Shift mechanism, installation position

- 1 — 5th/reverse gear selector shaft with swinging fork
- 2 — 3rd/4th gear selector shaft
- 3 — 1st/2nd gear shift fork
- 4 — relay shaft
- 5 — locking segment
- 6 — shift rod




► Fig. 3 Main shaft, pinion with hollow shaft, selector shafts and shift forks, installation position

- these parts must be installed together




► Fig. 4 Selector shaft bushing, removing

- with puller A, i.e. Kukko 21/3  
18.5 mm - 23.5 mm




► Fig. 5 Shift fork bearing, removing/installing



► Fig. 6 Oil collector, removing/installing


- pry out oil collector (arrow) with screwdriver
- push oil collector far enough into gear carrier housing that oil collector locking tab snaps into gear carrier housing
  - collector cup points upwards in gear carrier housing



► Fig. 7 Inner shift rod/relay shaft, installing

After installing the main shaft, pinion shaft and selector shafts, the inner shift rod and relay shaft can be installed as follows


- engage 3rd gear
- install relay shaft A
- install inner shift rod B sideways in housing and join to relay lever eye
- rotate inner shift rod in direction of arrow



► Fig. 8 Inner shift rod oil seal, replacing (transmission installed)

- remove exhaust system as necessary
- remove shift rod
- pry out seal using small screwdriver
- install new seal with VW 423
  - installed position a 1.0 mm


CONTINUED IN THE  
BEGINNING OF NEXT ROW



# Manual Transmission – Controls, Assembly


## Note

Cover can also be removed/installed with Torsen differential.




34-1929






► Fig. 1 Torsen differential grooved ball bearing, removing


- A — separating device 12 - 75 mm, i.e. Kukko 17/1




► Fig. 2 Torsen differential grooved ball bearing, installing



► Fig. 3 Drive flange grooved ball bearing, removing




► Fig. 4 Drive flange grooved ball bearing, installing



► Fig. 5 Cap, removing

- insert M8 screw into threaded hole of cap **B** and pull cap out




► Fig. 6 Drive flange, removing

- spread circlip to remove drive flange
  - when installing drive flange, also install circlip


**Note**

Do not over stretch circlip, it must lie in the base of the groove.




► Fig. 7 Needle bearing, removing

- drive out with puller **A**, i.e. Kukko 21/4 23.5 mm - 30 mm




► Fig. 8 Needle bearing, installing




► Fig. 9 Needle bearing, installation position

- dimension a = 14 mm




► Fig. 10 Sealing ring, installing

- drive sealing ring in to 2 mm below cover inner edge



► Fig. 11 Torsen differential, installing




Beginning with transmission 21 07 9, the threaded hole (arrow) in the main shaft, which is used for installing the ball bearing, is discontinued.

When installing the bearing in transmissions without the threaded hole, use tool 3235. The procedure for removing the bearing is unchanged.

## Ball bearing, installing in housing

- push bearing as far as possible onto main shaft
- install thrust pad A (part of tool 3235) on bearing
- install 3235 behind clutch plate splines on main shaft
- press bearing in by turning two bolts B alternately in stages



### Note

The ends of bolts B must align with the two depressions in the thrust pad when depressing.

### CAUTION

Turn each bolt **ONLY** a half turn at a time to prevent damage to the bearing.

## Oil drilling in main shaft, deleted

Also beginning with transmission 21 07 9, the oil drilling (arrow) for 3rd/4th gear is no longer present in **some** transmissions.

The needle bearing A to support the main shaft in the transmission housing is then installed without the plastic sleeve B.

If, during repairs, the main shaft is replaced with a shaft that has the oil drilling, the plastic sleeve must be installed.

