

Index

097 4-speed Automatic

ATF pump

- assembly 38.17
- replacing 38.5

Clutches K1 and K2

- adjusting/checking freeplay 38.13

One-way clutch (F)

- assembly 38.18
- disassembling/assembling 38.19
- installing 38.6

Planet carrier

- adjusting/checking 38.8

Reverse brake (B1)

- adjusting/checking 38.10

Reverse clutch (K2)

- installing 38.6

Second/fourth gear brake (B2)

- adjusting 38.15
- replacing plates 38.5

Small driveshaft

- replacing bolt 38.7

Third/fourth gear clutch (K3)

- installing 38.6

Transmission

- assembly 38.2

1st to 3rd gear clutch (K1)

- assembly 38.21
- disassembling/assembling 38.24

3rd/4th gear clutch (K3)

- assembly 38.27
- spring support clip 38.29

Parking lock


- assembly 38.35
- gear change shaft assembly 38.37
- lock spring bolts 38.38
- parking pawl pin 38.37
- sealing plug 38.38

Reverse clutch (K2)

- assembly 38.25
- spring support clip 38.26

Valve body

- assembly 38.31
- disassembling/assembling 38.34
- identifying 38.33
- installed position 38.34
- manual valve assembly 38.34
- oil strainer 38.33
- sealing plug 38.34



CAUTION

Before disassembling planetary gear set, remove valve body. See Repair Group 38.

1 — End cover

- pry out with screwdriver
- drive in with sleeve 40-20

2 — Bolt — 30 Nm (22 ft lb)

for small driveshaft

3 — Washer

4 — Shim

- for planet carrier
- determining thickness, page 38.8
- adjusting planet carrier: remove drive gear, Repair Group 39

5 — Transmission housing

- valve body assembly, page 38.31
- disassembling/assembling pinion, Repair Group 39
- mounting in repair stand, page 38.5

6 — Washer

lugs toward axial needle bearing

7 — Axial needle bearing

install in planet carrier with washers


Automatic Transmission — Case, Gears, Shaft

- 8 — Washer
- 9 — O-ring
 - always replace
 - install in planet carrier
- 10 — Planet carrier
 - lightly grease washers and needle bearing
 - place washers and needle bearing on planet carrier, then install planet carrier plates
- 11 — Shim
 - for reverse gear brake (B1)
 - determining thickness, page 38.10
- 12 — Inner splined plate
 - number of plates, see Technical data, Repair Group 37
 - before installing new plates, soak in ATF for 15 minutes
- 13 — Outer splined plate
 - number of plates, see Technical data, Repair Group 37
- 14 — Pressure plate
 - flat side toward plates
- 15 — Plate spring
 - curved side toward one-way clutch
- 16 — One-way clutch
 - with B1 piston
 - assembly, page 38.18
 - installing, page 38.6
- 17 — Circlip
 - for one-way clutch
 - after installing circlip, install oil deflector
 - installed position, page 38.6
- 18 — Oil deflector
 - seat in transmission housing groove (near ATF vent hole)
 - install deflector **after** installing circlip for one-way clutch and **before** installing circlip for support tube
- 19 — Circlip
 - for support tube
 - before installing circlip, be sure one-way clutch and oil deflector are in place
 - installed position, page 38.6
- 20 — Sun gear, small
 - install in planet carrier
- 21 — Washer
 - install with rounded side toward small sun gear
- 22 — Axial needle bearing
- 23 — Sun gear, large
 - install in planet carrier
- 24 — Washer
 - install with chamfered side in large sun gear
- 25 — Axial needle bearing
- 26 — Driveshaft, large
 - install in planet carrier
- 27 — Axial needle bearing
- 28 — Needle bearing
- 29 — Driveshaft, small
 - install in planet carrier
- 30 — Axial needle bearing
 - washer may be integral with needle bearing
 - bearing faces small driveshaft
- 31 — Washer
 - lugs toward axial needle bearing
 - washer may be integral with needle bearing
- 32 — 3rd/4th gear clutch (K3)
 - with pump shaft
 - removing/installing, page 38.6
 - assembly, page 38.27
- 33 — Washer
 - lugs toward axial needle bearing
- 34 — Axial needle bearing
- 35 — Washer
- 36 — 1st to 3rd gear clutch (K1)
 - with turbine shaft
 - assembly, page 38.21
- 37 — Shim
 - for K1/K2 freeplay adjustment
 - determining thickness, page 38.13
- 38 — Shim
 - for K1/K2 freeplay adjustment (if second shim is needed)
 - determining thickness, page 38.13
- 39 — Reverse clutch (K2)
 - installing, page 38.52
 - assembly, page 38.25
- 40 — Support tube
 - installing, page 38.6
 - install so that groove engages in wedge of one-way clutch
- 41 — Outer splined plate
 - number of plates, see Technical data, Repair Group 37
 - always install 3 mm thick outer plate, page 38.5
- 42 — Inner splined plate
 - number of plates, see Technical data, Repair Group 37
 - before installing new plates, soak in ATF for 15 minutes
 - installing, page 38.5
- 43 — Spring cap
 - remove all three
 - insert, after installing 1st outer splined plate
- 44 — Outer splined plate
 - number of outer plates, see Technical data, Repair Group 37
 - always install 2 mm thick outer plate, page 38.5
- 45 — Spring
 - remove all three
 - insert, before installing the last outer splined plate
- 46 — Spring cap
 - remove all three
 - insert, before installing the last outer splined plate

- 47 — **Outer splined plate**
 - number of outer plates, see Technical data, Repair Group 37
 - determining thickness of outer plates, page 38.15
 - installing, page 38.5
- 48 — **Spring washer, wavy**
- 49 — **Gasket**
 - always replace
- 50 — **O-ring**
 - always replace
 - place on ATF pump
- 51 — **ATF pump**
 - assembly, page 38.17
 - removing/installing, page 38.5
- 52 — **10 Nm (7 ft lb)**

Transmission, disassembling/ assembling

Mounting transmission in repair stand




ATF pump, replacing

- extract pump from transmission housing by turning bolts A

Note

When installing pump, ensure that gasket is seated.




2nd/4th gear brake (B2) plates, replacing


- remove all plates, springs and caps, together with clutches
- install 3 mm outer plate
- install spring caps/springs (three each)
- install all inner plates and 2 mm outer plates (see illustration 37-843 for installation sequence)

Note

Before installing the last measured outer plate, place a spring cap over each of the three springs.




Reverse clutch (K2) and support tube, installing




- install reverse clutch on shims
- install support tube (arrow) so that groove engages in wedge of one-way clutch

3rd/4th gear clutch (K3), installing



- assemble 1st to 3rd gear clutch (K1) and 3rd/4th gear clutch (K3) with washers and axial needle bearing (see illustration 37-843 for installation sequence)
- install assembly, altogether

Circlip for one-way clutch (F) and circlip for support tube, installed position




Note

Install oil deflector **after** installing circlip for one-way clutch and **before** installing circlip for support tube


One-way clutch, installing

- position arbor **2003/2A** on planet carrier as shown
- press one-way clutch over arbor, onto planet carrier



Bolt for small driveshaft, replacing

- bolt located in bore of driveshaft and large sun gear



Planet carrier, adjusting/checking



Note

The following components should already be assembled to the small driveshaft:

- planet carrier with washers and needle bearing
- small sun gear
- drive gear with axial needle bearing

Shim thickness, determining

- set up measuring equipment as shown
 - dial indicator sensor must contact small driveshaft
- "zero" dial indicator, with 3 mm preload



- reposition dial indicator sensor onto axial needle bearing
- record measurement
 - example: 2.00 mm
- use recorded measurement to select appropriate shim thickness from chart which follows:


Dial Gauge Measurement	Thickness Shim (mm)
1.26 ... 1.35	1.0
1.36 ... 1.45	1.1
1.46 ... 1.55	1.2
1.56 ... 1.65	1.3
1.66 ... 1.75	1.4
1.76 ... 1.85	1.5
1.86 ... 1.95	1.6
1.96 ... 2.05	1.7
2.06 ... 2.15	1.8
2.16 ... 2.25	1.9
2.26 ... 2.35	2.0
2.36 ... 2.45	2.1
2.46 ... 2.55	2.2
2.56 ... 2.65	2.3
2.66 ... 2.75	2.4
2.76 ... 2.85	2.5
2.86 ... 2.95	2.6
2.96 ... 3.05	2.7
3.06 ... 3.15	2.8
3.16 ... 3.25	2.9

Example


For a measurement of 2.00 mm, select a 1.7 mm shim.

Adjustment, checking

- set up measuring equipment, with dial indicator contacting small driveshaft bolt head
- move small shaft to upper/lower limits of travel
- measure freeplay
 - freeplay minimum: 0.23 mm
 - freeplay maximum: 0.37 mm



Reverse brake (B1), adjusting/ checking



Shim thickness, determining

Note

A shim selection chart appears in this section. Thickness values in the chart are determined by the value of Gap x , which must be calculated in the following equation:

$$\text{Gap } x = k + \frac{T}{2} - m$$

k = constant value = 26.8 mm

K is determined per transmission housing and number of plates:

$k =$	No. of plates	
	inner	outer
26.8	5	5
30.5	6	6

The remaining variables (T , m) in the equation are measured, as follows:

Variable T , determining

- place straightedge **A** on outer race of one-way clutch
- press piston in, to stop, in direction of arrows
- measure inner edge of piston with depth gauge **B**

Example

depth gauge reading	51.8 mm
– straightedge thickness	48.2 mm

$$T = 3.6 \text{ mm}$$



Variable m , determining

- place straightedge **A** on thrust plate
- press plates together in direction of arrows
- measure thickness of plate set using depth gauge **B**

Example

depth gauge reading	73.5 mm
– straightedge thickness	48.2 mm

$$m = 25.3 \text{ mm}$$



Value of Gap x, calculating

Example

$$\begin{aligned}
 \text{Gap } x &= k + \frac{T}{2} - m \\
 &= 26.8 + \frac{3.6}{2} - 25.3 \\
 &= 3.3 \text{ mm}
 \end{aligned}$$

Note


Use calculated value for Gap x (derived from actual measurements) to select appropriate shim thickness(es):

Gap x (mm)	Shim (mm)
2.36 ... 2.45	1.0
2.46 ... 2.55	1.1
2.56 ... 2.65	1.2
2.66 ... 2.75	1.3
2.76 ... 2.85	1.4
2.86 ... 2.95	1.5
2.96 ... 3.05	1.6
3.06 ... 3.15	1.7
3.16 ... 3.25	1.8
3.26 ... 3.35	1.9
3.36 ... 3.45	1 + 1
3.46 ... 3.55	1 + 1.1
3.56 ... 3.65	1.1 + 1.1
3.66 ... 3.75	1.1 + 1.2
3.76 ... 3.85	1.2 + 1.2
3.86 ... 3.95	1.2 + 1.3
3.96 ... 4.05	1.3 + 1.3
4.06 ... 4.15	1.3 + 1.4
3.16 ... 4.25	1.4 + 1.4

Adjustment, checking

Note

Ensure that components up to one-way clutch are properly assembled and secured with circlip.



- measure freeplay between plates with feeler gauge **A**
 - freeplay minimum 1.20 mm
 - freeplay maximum 1.80 mm

Clutches K1 and K2, adjusting/ checking freeplay

Note

K1 = 1st to 3rd gear clutch

K2 = reverse gear clutch

Shim thickness, determining

Note


A shim selection chart appears in this section. Thickness values in the chart are determined by the value of Gap **x**, which must be calculated in the following equation:

$$\text{Gap } x = y - z$$

Variables **y** and **z** in the equation are measured as follows:

Variable **y**, determining

- place straightedge **A** on transmission housing
- press **K1** down, in direction of arrows
- measure into **K1** with depth gauge **B**




Example

depth measurement 1 = 88.5 mm

Note

Record value, and take depth measurement 2:

- place straightedge **A** on transmission housing
- position depth gauge **B** on straightedge **A** and measure to ATF pump flange




Example

depth measurement 2 = 34.3 mm

$$\begin{aligned} y &= \text{measurement 1} - \text{measurement 2} \\ &= 88.5 \text{ mm} - 34.3 \text{ mm} \\ &= 54.2 \text{ mm} \end{aligned}$$

measurement from pump flange into **K1**

Automatic Transmission – Case, Gears, Shaft



Variable z, determining

- place straightedge **B** on stator support as shown
- measure to pump flange gasket with depth gauge **A**

Example

depth gauge reading	70.5 mm
– straightedge thickness	19.5 mm
	z = 51.0 mm

Value of Gap x, calculating

Example

$$\begin{aligned}
 \text{Gap } x &= y - z \\
 &= 54.2 \text{ mm} - 51.0 \text{ mm} \\
 &= 3.2 \text{ mm}
 \end{aligned}$$

Note

Use calculated value for Gap **x** (derived from actual measurements) to select appropriate shim thickness(es):

Gap x (mm)	Shims (mm)
. . . . 2.54	1.4
2.55 3.09	1 + 1
3.10 3.49	1.2 + 1.2
3.50 3.89	1.4 + 1.4
3.90 4.29	1.6 + 1.6
4.30 4.69	1.8 + 1.8
4.70 5.04	1.2 + 1.2 + 1.6
5.05 5.25	1.2 + 1.2 + 1.8

Adjustment, checking

See Clutch adjustment, checking (page 38.16)

2nd/4th gear brake (B2), adjusting

Last outer splined plate, determining thickness

Note

A shim selection chart appears in this section. Thickness values in the chart are determined by the value of Gap x , which must be calculated in the following equation:

$$\text{Gap } x = y - z - k$$

k = constant value = 3.6


The remaining variables (y , z) in the equation are measured as follows:

Variable y , determining

- press inner splined plate (arrows) downward
- measure from pump flange **A** to last inner splined plate, using depth gauge **B**

Example

gauge reading = variable y = 30.2 mm



Variable z , determining

- place straightedge **A** on stator support as shown
- measure to pump flange gasket with depth gauge **B**


Example

depth gauge reading	40.1 mm
- straightedge thickness	19.5 mm
	z = 20.6 mm

Value of Gap x , calculating

Example

$$\begin{aligned} \text{Gap } x &= y - z - k \\ &= 30.2 - 20.6 - 3.6 \\ &= 6.0 \text{ mm} \end{aligned}$$



Note

Use calculated value for Gap x (derived from actual measurements) to select appropriate plate thickness(es):


Gap x (mm)	Plate (mm)
4.25. . . . 4.49	2.75
4.50. . . . 4.74	3.00
4.75. . . . 4.99	3.25
5.00. . . . 5.24	3.50
5.25. . . . 5.49	3.75
5.50. . . . 5.74	2.00 + 2.00
5.75. . . . 5.99	2.00 + 2.25
6.00. . . . 6.24	2.25 + 2.25
6.25. . . . 6.49	2.25 + 2.50
6.50. . . . 6.74	2.50 + 2.50
6.75. . . . 7.00	2.50 + 2.75

Clutch adjustment, checking

Note

Install ATF pump before measuring clutch freeplay.


- secure dial indicator holder **VW 387** to transmission housing
- position dial indicator sensor on turbine shaft, with 1 mm preload
- move turbine shaft to upper/lower limits of travel
 - freeplay minimum 0.5 mm
 - freeplay maximum 1.2 mm



THIS FRAME INTENTIONALLY LEFT

BLANK

Automatic Transmission – Case, Gears, Shaft



1 — Piston rings
check for proper seating

2 — Thrust washer

3 — Piston
• coat sealing lips with ATF before installing piston
• turn piston slightly while installing

4 — 10 Nm (7 ft-lb)

5 — Stator support


6 — Outer gear
• coat with ATF before installing
• marked side must face stator support
• if installed incorrectly, pump may turn stiffly

7 — Inner gear
coat with ATF before installing

8 — ATF pump housing

9 — O-ring
always replace

10 — Oil seal for torque converter
removing/installing, see Repair Group 32



38-686


- 1 — **Rollers**
installing, page 38.19
- 2 — **Springs**
installing, page 38.19
- 3 — **Cage**
installing/securing, page 38.19

- 4 — **Outer ring**
- 5 — **Piston**
 - coat sealing lips with ATF before installing piston
 - turn piston slightly while installing
 - installed position, page 38.20

One-way clutch with B1 piston, disassembling/assembling


Springs/rollers, installing

- install spring (arrow) so that it seats in cage




Spring/roller cage assembly, installing

- install with lugs (arrow) upward



Cage assembly, securing


- turn cage in direction of arrow, to stop




Automatic Transmission – Case, Gears, Shaft

Piston, installed position

- install piston A as shown



Automatic Transmission – Case, Gears, Shaft



38-689

CAUTION

During clutch repair, inspect ball valve (arrow) for damage.

1 — Support ring

- has four segments
- unclip from inner splined plate carrier
- installing, page 38.24

2 — Inner splined plate carrier assembling, page 38.24

3 — Circlip

- mark after removal and install in same position
- different thicknesses available
- removing/installing, page 38.24

4 — Thrust plate

- smooth side faces inner plates
- install together with inner plate carrier

5 — Inner splined plate


- number of plates, see Technical data, Repair Group 37
- installing, page 38.24

- 6 — **Outer splined plate**
 - number of plates, see Technical data, Repair Group 37
 - installing, page 38.24
- 7 — **Thrust plate**
curved side faces diaphragm spring
- 8 — **Circlip**
removing/installing, page 38.23
- 9 — **Diaphragm spring**
curved side faces piston
- 10 — **Circlip**
removing/installing, page 38.23
- 11 — **Spring intermediate ring assembly**
with guide for compression springs
- 12 — **Operating ring**
rounded surface faces spring intermediate ring assembly
- 13 — **Plate spring**
 - curved side faces operating ring
 - installing, page 38.23
- 14 — **Plate spring**
 - curved side faces piston
 - installing, page 38.23
- 15 — **Piston**
 - coat sealing lips with ATF before installing piston
 - turn piston slightly while installing
- 16 — **Piston ring, smaller**
to remove, unhook ends
- 17 — **Piston ring, larger**
to remove, unhook ends
- 18 — **Clutch drum with turbine shaft**
 - replace drum if bushings are damaged
 - before installing inner plate carrier, place an inner and outer plate in clutch drum
 - assembling, page 38.24
- 19 — **Piston rings**
to remove, unhook ends

1st to 3rd gear clutch (K1) with turbine shaft, disassembling/ assembling


Plate springs, installing

- install plate springs 1 and 2 so that outer edges make contact
 - at inner diameter of plates there is clearance



Circlip at spring intermediate ring assembly, removing/installing

- set up pressing equipment as shown
- push spring intermediate ring downward until circlip (**arrow**) can be seated/unseated at groove




Circlip at diaphragm spring, removing/ installing

- seat/unseat circlip (**arrow**) at groove

Note

Diaphragm spring is slightly preloaded.




Inner splined plate carrier, assembling

- install thrust plate
- install inner and outer plates
- clip support ring to carrier


Note

One inner and one outer plate must be placed in clutch drum before inner splined plate carrier is installed (see below).




Clutch drum, assembling


- install thrust plate
- install one inner plate
- install one outer plate



Circlip at inner splined plate carrier, removing/installing

- seat/unseat circlip (arrow) at groove





CAUTION

During clutch repair, inspect ball valve (arrow) for damage.


- 1 — Circlip
 - mark after removal and install in same position
 - different thicknesses available
- 2 — Thrust plate
 - shouldered side faces circlip
- 3 — Outer plate
 - number of plates, see Technical data, Repair Group 37

- 4 — Inner plate
 - number of plates, see Technical data, Repair Group 37
- 5 — Spring washer, wavy
- 6 — Circlip
 - removing/installing, page 38.26
- 7 — Spring support plate
 - with springs
 - installed position, page 38.26
- 8 — Spring support ring
- 9 — Piston
 - coat sealing lips with ATF before installing piston
 - turn piston slightly while installing
- 10 — Clutch drum with clutch tube

Circlip for reverse clutch (K2) spring support assembly, replacing

Removing

- set up pressing equipment as shown
- push spring support plate downward



CAUTION

Spring plate bends easily.


- spread/remove circlip

Installing


- position new circlip
- press new circlip down carefully with spring support plate, as in removal
- seat circlip in groove at clutch drum

Installed position, checking

- check that circlip (**arrow**) is fully seated at clutch drum
- check that spring support plate is concentric with hub
 - if not, plate will bend



Automatic Transmission – Case, Gears, Shaft



38-688

CAUTION

During clutch repair, inspect ball valve (arrow) for damage.

- 1 — Circlip
 - mark after removal and install in same position
 - different thicknesses available
- 2 — Pressure plate
 - shouldered side faces circlip
- 3 — Inner plate
 - number of plates, see Technical data, Repair Group 37


- 4 — Outer plate
 - number of plates, see Technical data, Repair Group 37
- 5 — Thrust plate
 - rounded side faces ring
- 6 — Ring
 - install in rounded side of thrust plate
- 7 — Circlip
 - replacing, page 38.29
- 8 — Spring support ring
- 9 — Springs
 - place on support ring

Automatic Transmission — Case, Gears, Shaft


- 10 — **Spring support plate**
- 11 — **Circlip**
 - seat in grove at clutch drum
- 12 — **Diaphragm spring**
 - curved side faces piston
- 13 — **Piston**
 - coat sealing lips with ATF before installing piston
 - turn piston slightly while installing
- 14 — **Clutch drum with pump shaft**
- 15 — **Piston rings**
 - remove/replace only if defective
 - are destroyed during removal
- 16 — **Piston rings**
 - to remove, unhook ends

Circlip for 3rd/4th gear clutch (K3) spring support assembly, replacing

- set up pressing equipment as shown
- seat new circlip at spring support assembly (arrow)



**intentionally
left blank**



38-719

Note

The valve body can be removed with transmission in vehicle. Replace valve body if unit is contaminated or defective.

After installing oil pan, refill with ATF to specifications.

CAUTION

Do not run engine or tow vehicle with oil pan removed, or without oil in transmission.

- 1 — Oil pan
remove ATF filler tube before removing oil pan

2 — 10 Nm (7 ft lb)

3 — Gasket

- always replace
- press spacer into gasket

4 — Spacer

- press into gasket


5 — Oil strainer

- seat seal
- installed position, page 38.33


6 — Valve body

- installed position, page 38.34
- identifying, page 38.33

- 7 — 10 Nm (7 ft lb)
- 8 — **Wiring connector**
install with O-ring
- 9 — **O-ring**
always replace
- 10 — **Sealing plug**
 - remove plug before removing/installing one-way clutch
 - installing, page 38.34
- 11 — **O-ring**
always replace
- 12 — **O-ring**
always replace
- 13 — **Operating rod for manual valve**
 - positioning, page 38.34
 - shouldered side faces manual valve
- 14 — **Final drive housing**
- 15 — **Seal**
 - always replace
 - seat in oil strainer
- 16 — 5 Nm (44 in. lb or 51 cm kg)
- 17 — 8 Nm (71 in. lb or 82 cm kg)
- 18 — **ATF filler tube**
tightening torque at oil pan: 80 Nm (59 ft lb)
- 19 — 10 Nm (7 ft lb)



Oil strainer, installed position




Valve body, identifying

Note

Code letters are stamped on a metal tag which must remain attached to the valve body.

For valve body application, see Technical data in Repair Group 37.

Valve body, disassembling/assembling




Sealing plug, installing


- install O-rings on plug
- install plug so that lug seats in groove on housing

CAUTION

Before removing/installing one-way clutch, remove sealing plug from housing to avoid damage to plug and O-ring.



Valve body, installed position




Manual valve assembly, installing

- move shaft to selector lever position **P**
- install manual valve assembly fully into valve body
 - operating rod **A** positioned in direction of **arrow**
- tighten stop screw **B** to 4 Nm (35 in. lb or 41 cm kg)

CAUTION

The manual valve lever **C** must remain against stop screw **B** during installation. When tightening screw **B** at manual valve lever **C**, counter-hold lever in direction of **arrow**.

Automatic Transmission – Case, Gears, Shaft



38-721

- 1 — 10 Nm (7 ft lb)
- 2 — Sealing plug
installing, page 38.38

- 3 — O-ring
always replace
- 4 — Parking pawl
 - install with return spring
 - align with parking lock gear
- 5 — Parking lock gear
rounded side faces pinion cover


- 6 — Pin for parking pawl
 - removing, page 38.37
 - drive in with mandrel
 - staking, page 38.37

- 7 — Return spring
- 8 — Retainer
for multi-function switch
- 9 — 10 Nm (7 ft lb)
- 10 — Multi-function switch (F125)
- 11 — O-ring
always replace

- 12 — Cap
- 13 — Final drive housing
- 14 — O-ring
 - always replace
- 15 — Speed sensor
- 16 — 10 Nm (7 ft lb)
- 17 — Lever for gear change shaft
- 18 — 10 Nm (7 ft lb)
- 19 — Bushing
 - remove/install with mandrel
- 20 — O-ring
 - always replace
 - seat in groove of gear change shaft
 - installed position, page 38.37
- 21 — Gear change shaft assembly
 - before withdrawing shaft, remove multi-function switch and lock spring
 - securing, page 38.37
 - always install with lever
- 22 — Lock washer
 - installed position, page 38.37
- 23 — 10 Nm (7 ft lb)
- 24 — Manual valve lever
- 25 — 4 Nm (35 in. lb or 41 cm kg)
- 26 — Lock spring
 - installation sequence for bolts, page 38.37
- 27 — 10 Nm (7 ft lb)
 - installing, page 38.37
- 28 — Lever


Parking lock, disassembling/ assembling

Pin for parking pawl, removing



Pin for parking pawl, staking

- secure pin by staking with punch
A at final drive housing




Gear change shaft assembly, installed
position


- A — gear change shaft
- B — O-ring
- C — multi-function switch (F125)

Note

Shaft is held stationary by lock washer
(arrow).




Automatic Transmission – Case, Gears, Shaft



Bolts for lock spring, installation sequence

- start both bolts into housing
 - approximately 3 threads
- tighten bolt 2 to 10 Nm (7 ft lb)
- tighten bolt 1 to 10 Nm (7 ft lb)



Sealing plug, installing